

# **IP Horn Speaker**

## **User Manual**



# Contents

1. Brief Introduction .....	1
2. Product Package Content.....	1
3. PoE Injector connection structure diagram.....	2
4. Web picture.....	3
5. Set the main interface.....	4
6. Network (Network Environment).....	5
6.1 Status (network status) .....	5
6.2 WAN Setting (WAN network setting).....	6
6.3 SNTP Setting.....	7
7. SIP Setting.....	8
7.1 Service Domain (broad system server registration setting).....	8
7.2 Port Setting (SIP and RTP port setting) .....	9
7.3 Codec Setting (voice format setting).....	10
7.4 Audio Setting provides speaker volume and sound detection function.....	11
7.5 Other Setting .....	12
8. Update .....	13
8.1 Update New Firmware .....	13
8.2 Default Setting .....	15
9. System Authority.....	16
10. Save Change.....	17
11. Reboot.....	17
12. Waterproof network joint suite assembly example .....	18

## 1. Brief Introduction

A IP broadcast system is composed of a microphone, broadcast software (Windows computer) and IP Loudspeaker (or audio receiver). The IP Loudspeaker is connected through internet network. The broadcast can be in human voice and scheduling. The scheduling broadcast function is to play audio (MP3/WAV) in computer at appointed time, as well as edit group function to conduct group broadcast or multipoint broadcast. The system composition is simple. It is unnecessary to have wiring or purchase an amplifier or player if there is a network environment. The system's host and loudspeaker shall be set. The audio receivers can be installed in the broadcast system, to have network broadcast function.

## 2. Product Package Content:

- I. IP Speaker host X 1




**main body size : 280 X 200 X 280 mm**

- II. RJ45 waterproof joint's composite set contains



### 3. PoE Injector connection structure diagram

LAN port : RJ-45 network port(PoE) ; connected to PoE Injector through network cable  
P+D/OUT port conducts network connection and power supply




## 4 Web picture

Step 1: open IE browser (or other browser software), input [http://192.168.0.100]

Step 2: enter [Login WEB] picture, input [Username & Password (defaults: username: voip, Password: 1234)] data, and then click [OK] to enter the equipment management interface after confirming the password is correct (as shown in the following picture).




Step 3: enter the system to see [System Information], providing view of Model Name and Firmware Version, Codec Version, etc. (as shown in the following picture).



## 5. Set the maininterface

It provides the following function items: Network, SIP Setting, System Auth, (Account and Password Change), Save Change, Update and Reboot.



- (1).Network : Network provides Status and WAN Setting
- (2).SIP Settings : SIP Setting provides Service Domain (SIP registration setting), Port Setting (SIP and RTP ports setting), Code Setting (voice format setting), Audio Setting (loudspeaker volume and sound detection setting), Other Setting.
- (3).Update : Update (firmware updating) provides Firmware (firmware updating), Default Settings (factory reset).
- (4).System Authority : System Auth (Account and Password change) provides change of user's account and password.
- (5).Save Change : Save Change provides setting of save change environment.
- (6).Reboot : Reboot provides the function of rebooting a device.

## 6. Network (Network Environment)

### 6.1 Status (network status)

Network Status (network status) picture shows the date of current network environment status (as shown in the following picture).

**Net Status**

Master	WAN Interface
Type	DHCP Client
IP	192.168.0.127
Mask	255.255.255.0
Gateway	192.168.0.254
MAC	00037E0152F9

Column	Introduction
Master	Show the network environment data of the network port (WAN port)
Type	Show current network connection mode
IP	Show set or gained network address data
Mask	Show set or gained network coding data
Gateway	Show set or gained preset gateway data
MAC	Show MAC position data of the machine

## 6.2 WAN Setting (WAN network setting)

WAN Setting (WAN network setting) picture provides WAN network connection mode.

**Network**

Status

**WAN Setting**

SNTP Settings

**SIP Settings**

Update

System Authority

Save Change

Reboot

### WAN Setting

WAN Setting	
IP Type	<input checked="" type="radio"/> Fixed IP <input type="radio"/> DHCP Client <input type="radio"/> PPPoE
Master IP	<input type="text" value="192.168.0.100"/>
Mask	<input type="text" value="255.255.255.0"/>
Gateway	<input type="text" value="192.168.0.254"/>
DNS Server1	<input type="text" value="168.95.192.1"/>
DNS Server2	<input type="text" value="168.95.1.1"/>
MAC	<input type="text" value="00037e0152f9"/>
Host Name	<input type="text" value="IS-0152F9"/>

PPPoE Setting	
User Name	<input type="text"/>
Password	<input type="text"/>

WAN Setting	Provide WAN port network environment setting data
IP Type	Preset to be DHCP Client network mode. Provide Fixed IP, DHCP Client (automatically obtain an IP address) and PPPoE mode. Fixed IP: set IP address manually. DHCP Client (automatically obtain an IP address): automatically obtain an IP address. PPPoE (connect PPPoE): adopt PPPoE connection mode.
IP	Show IP address data. Show gained or set IP address data.
Mask	Show subnet mask data. Show gained or set subnet mask address data.
Gateway	Show preset gateway data. Show Show gained or set preset gateway address data.
DNS Server1	Preset to be 168.95.192.1; show gained or set first DNS server's address data; IP or Domain Name can e input
DNS Server2	Preset to be 168.95.1.1; show gained or set second DNS server's address data; IP or Domain Name can e input
MAC	Show MAC position data of the machine
PPPoE Setting	Provide PPPoE connection data
User Name	Set connection account name, in which figures or strings are available
Password	Set connection account password, in which figures or strings are available
Submit [key]	Execute storage and change setting.
Reset [key]	Clear input data.

**\* Press [submit] to finish storage setting after changing the data to be adjusted, and select the main menu's [SaveChange], to execute storage change setting, the system will restart automatically \***



## 6.3 SNTP Setting

**SNTP Setting** picture provides server address and timing time.

**SNTP Settings**

SNTP:  On  Off

Primary Server:

Secondary Server:

Time Zone: GMT   :  (hh:mm)

Sync. Time:  :  :  (dd:hh:mm)

Column	Introduction
SNTP	Preset to be On (start); timing function. Turn off timing function when it is set to be Off.
Primary Server	Preset to be time.windows.com; the first syn-position timing server address. Input IP or Domain Name address.
Secondary Server	Preset to be 208.184.49.9; the second syn-position timing server address. Input IP or Domain Name address.
Time Zone	Preset to be GMT + 08:00 (hh:mm); time zone material.
Sync. Time	Preset to be 1:00:00 (1 day); timing time. Correct the host time every a certain period.
Submit [key]	Execute storage and change setting.
Reset [key]	Clear input data.

**\* Press [submit] to finish storage setting after changing the data to be adjusted, and select the main menu's [SaveChange], to execute storage change setting, the system will restart automatically \***

## 7. SIP Setting

### 7.1 Service Domain (broad system server registration setting)

Service Domain (registration setting) picture provides registration account data and state.

**Service Domain Settings**

Channel 1 ▾

Active:  ON  OFF

Register Name:

Register Password:

IPB Server:  ×

Status: Registered

Column	Introduction
Active	Preset to be Off; put the account into use. Put the registration account into use when it is set to be On.
Register Name	Input registration name data. Input digits or string.
Register Password	Input registration password data. Input digits or string.
IPB Server	Input the registration broadcast system's server data. Input IP or Domain Name address.
Status	Show current registration status data. Not Register (failed), Register (successful).

**\* Press [submit] to finish storage setting after changing the data to be adjusted, and select the main menu's [SaveChange], to execute storage change setting, the system will restart automatically \***

## 7.2 Port Setting (SIP and RTP port setting)

Port Setting (SIP and RTP port setting) picture provides setting of SIP and RTP communication port positions.

The screenshot displays the 'Ports Setting' configuration page. On the left, a navigation menu includes 'Network', 'SIP Settings', 'Service Domain', 'Port Setting' (highlighted with a red box), 'Codec Setting', 'Audio Setting', 'Other Setting', 'STUN Setting', 'Update', 'System Authority', 'Save Change', and 'Reboot'. The main area is titled 'Ports Setting' and contains two rows of settings:

SIP Port	<input type="text" value="5060"/>	(1024~65533)
RTP Port	<input type="text" value="20000"/>	(1024~65533)

Below the input fields are two buttons: 'Submit' and 'Reset'.

Column	Introduction
SIP Port	Preset to be 5060; set SIP port position.
RTP Port	Preset to be 20000; set RTP port position.
Submit [key]	Execute storage and change setting.
Reset [key]	Clear input data.

**\* Press [submit] to finish storage setting after changing the data to be adjusted, and select the main menu's [SaveChange], to execute storage change setting, the system will restart automatically \***

## 7.3 Codec Setting (voice format setting)

Code Setting (voice format setting) picture provides Codec format priority, RTP package size and VAD function.

**Network**

**SIP Settings**

Service Domain

Port Setting

**Codec Setting**

Audio Setting

Other Settings

**Update**

System Authority

Save Change

Reboot

### Codec Setting

Codec Priority	
Codec Priority 1:	G.711 u-law ▾
Codec Priority 2:	G.711 a-law ▾
Codec Priority 3:	Not Used ▾
Codec Priority 4:	Not Used ▾
Codec Priority 5:	Not Used ▾
Codec Priority 6:	Not Used ▾
Codec Priority 7:	Not Used ▾
Codec Priority 8:	Not Used ▾

RTP Packet Length	
G.711 & G.729:	20 ms ▾
G.723:	30 ms ▾

G.723 5.3K	
G.723 5.3K	<input type="radio"/> ON <input checked="" type="radio"/> OFF

Voice VAD	
Voice VAD	<input type="radio"/> ON <input checked="" type="radio"/> OFF

Column	Introduction
<b>Codec Priority</b>	Provide format priority of using voice.
Codec Priority 1	Preset to be G.711 u-law; the first syn-position voice format. Provide No used, G.711u-law, G. 711a-law, G.723, G.279, G.726–16, G.726–24, G.726–32, G.726–40 and so on.
Codec Priority 2	Preset to be G.711 u-law; the second syn-position voice format.
Codec Priority 3	Preset to be G.723; the third syn-position voice format.
Codec Priority 4	Preset to be G.729; the fourth syn-position voice format.
Codec Priority 5	Preset to be G.726-16; the fifth syn-position voice format.
Codec Priority 6	Preset to be G.726-24; the sixth syn-position voice format.
Codec Priority 7	Preset to be G.726-32; the seventh syn-position voice format.
Codec Priority 8	Preset to be G.726-40; the eighth syn-position voice format.
<b>RTP Packet Length</b>	Provide data of setting RTP package length
G.711 & G.729	Preset to be 20ms; G.711& G.729 package length Provide 10ms, 20ms, 30ms, 40ms, 50ms, 60ms, 70ms, 80ms, 90ms and other formats.
G.723	Preset to be 30ms; G,723 package length Provide 30ms, 60ms, 90ms and other formats.

G.723 5.3K	Provide data of setting G.726 5.3K
Voice VAD	Preset to be Off; G.723 5.3K function. Start 5.3K when it is set to be On.
Voice VAD	Provide data of setting Voice VAD
Voice VAD	Preset to be Off; voice detection function. Use VAD function when it is set to be On.
Submit [key]	Execute storage and change setting.
Reset [key]	Clear input data.

\* Press [submit] to finish storage setting after changing the data to be adjusted, and select the main menu's [SaveChange], to execute storage change setting, the system will restart automatically \*

7.4 Audio Setting provides speaker volume and sound detectionfunction.

**Audio Setting**

Speaker Volume:  (64~0)

Detection Sensitivity:  (32~0)

RTP Timeout:  seconds (0: disable)

Column	Introduction
Speaker Volume	Preset it to be 45; set speaker volume, 0-64.
Detection Sensitivity	Preset it to be 32; set the sensitivity of sound detection, 0-32.
RTP Timeout	Preset to be 10s: it can be set that the machine restores to idle status for a certain period during which the RTP package of the broadcast system server is not received
Submit [key]	Execute storage and change setting.
Reset [key]	Clear input data.

\* Press [submit] to finish storage setting after changing the data to be adjusted, and select the main menu's [SaveChange], to execute storage change setting, the system will restart automatically \*

## 7.5 Other Setting

Other Setting interface provides SIP Expire Time

The screenshot shows the 'Other Setting' interface. On the left, a sidebar menu contains the following items: Network, SIP Settings, Service Domain, Port Setting, Codec Setting, Audio Setting, Other Settings (highlighted with a red box), STUN Setting, Update, System Authority, Save Change, and Reboot. The main content area is titled 'Other Setting' and features a form for 'SIP Expire Time' with a text input field containing '60' and a range '(30~86400 sec)'. Below the input field are three buttons: 'CutLine', 'Submit', and 'Reset'.

SIP Expire Time	Preset to be 60; set registration interval; data setting section (30-86400).
CutLine	Interrupt present broadcast program and restore to idle status
Submit [key]	Execute storage and change setting.
Reset [key]	Clear input data.

**Press [submit] to finish storage setting after changing the data to be adjusted, and select the main menu's [SaveChange], to execute storage change setting, the system will restart automatically \***

## 8. Update

### 8.1 Update New Firmware


Code Type	Preset to be Risc (.gz). Select the type of documents to be updated. Provide Risc (system firmware. gz) and DSP (DSP firmware. ds) updating modes.
File Location	Input file position or name to be updated or press [Browse] to select file data; version name of the file to be updated.
Submit[key]	Execute storage and change setting.
Reset [key]	Clear input data.

Step 1: click [Updte ~~✖~~ New Firmware] on the surface to enter [Update Firmware], to set version to updated and select Code Type: Risc, then set File Location data, to set [Broswe] key (as shown in the following picture).

### Update Firmware

Ver = v1.130, GZ = r4IPA,x1, PCB = IS640.

Step 2: enter [select file] interface, to select [gz] file to be updated [for example, VP5110\_70105.gz], and then press [open] (as shown in the following picture), to return to the main interface.



Step 3: back to [Update Firmware], wherein [File Location] has data to be updated if it is confirmed to be correct; please press [Submit] to start updating (as shown in the following picture).

## Update Firmware

Ver = v1.130, GZ = r4IPA,x1, PCB = IS640.

Code Type:	<input type="text" value="RISC"/>
File Location:	<input type="text" value="C:\gz\f4Mv10x1_S0_L0_2N149A.gz"/> <input type="button" value="Browse..."/>
<input type="button" value="Submit"/> <input type="button" value="Reset"/>	

Step 4: enter [information prompt] picture, showing [please do not pull out power supply equipment at random in version updating, the updating time is about 3 minutes] (as shown in the following picture).

## Note Information

### Waiting Message

waiting for system updating & rebooting...

Step 5: return to the main interface after updating; please press [reload(F5)] to conduct other settings.



## 8.2 Default Setting

Restore Default Setting provides data content of all change setting (not containing data in Network) to restore default setting value; the system will automatically restart.



Column	Introduction
Restore [key]	Remove all change setting data to restore default setting.

Step 1: click [Update ~~➤~~ Default Setting] in the main interface to enter [Restore Default Settings]. Please press [Restore] to restore default, to clear all settings and restart the equipment automatically (as shown in the following figure).

## Restore Default Settings

Restore default settings: default

Step 2: enter the informatoin prompt interface to finish clear setting and restart the system, please wait (as shown in the following picture).

## Note Information

### Booting

Please wait for a moment while rebooting ...

Step 3: return to the main interface after starting up, please press [reload (F5)] to conduct other environment settings.

## 9. System Authority


Set system authority

Column	Introduction
New username	Input the new user's data Input digits or string.
New password	Input new password Input digits or string.
Confirmed password	Input and confirm password Input digits or string.
Submit [key]	Execute storage and change setting.
Reset [key]	Clear input data.

\* Press [Submit] to finish storage setting after changing the data to be adjusted. Select [Save Change] to execute storage change setting, and the system will reboot automatically\*

## 10. Save Change


Save Changes provides save changes setting and restarts the system automatically



Column	Introduction
Save [key]	Execute storage and change setting.

## 11. Reboot

Reboot System interface provides manual reboot.



Step 1: click [Reboot] in the main interface to enter [Reboot System] and then press [Reboot] to reboot the system (as shown in the following picture).

## Reboot System

Reboot system:

Column	Introduction
Reboot [key]	Reboot the equipment

Step 2: enter the information prompt interface, showing that the system is rebooting, please wait (as shown in the following picture); do not pull out power supply equipment at random at the moment.

## Note Information

### Booting

Please wait for a moment while rebooting ...

Step 3: back to the main interface after starting up, please press [reload (F5)] to conduct other environment settings.

## 12. Waterproof network joint suite assembly example

Step 1.



Step 2.



Step 3.



Step 4.



Step 5.

